



PV250-SV2 Vat Inlet Valve with CIP Non Return Valve Instruction Manual

Oasis Engineering Ltd 129 Birch Avenue, Tauranga, New Zealand. T: +64 7 928 3808 F: +64 7 928 3809 E: info@oasisNGV.com W: www.OasisNGV.com



Safety

Setting The Standard

Warning!

Ensure that the pipeline is relieved of all pressure and media before removing or installing a valve. Can cause serious harm to both infrastructure and personnel if safety precautions are not followed.

Oasis recommends considering the use of the following PPE when working with high pressure along with any other site specific health and safety requirements:



Tools Required





1. Position the valve in the correct position. Install RJT seals, pipe work and RJT nuts. The center port should be connected to the milk vat.



3



2. Tighten RJT nuts using a C spanner.



3. Install the CIP cleaning fluid supply and fix with a hose clamp. On first use check for leakage.



Oasis A MEMBER OF THE ELAFLEX GROUP

Operation Instructions

Setting The Standard

Plant Entry to Vat : Handle Vertical

The closed port is always opposite the handle.



Plant Cleaning : Handle Horizontal



Oasis Engineering Ltd. 129 Birch Ave, Tauranga, 3110, New Zealand, Ph +64 7 9283808, Info@oasisngv.com, www.oasisngv.com

We reserve the right to modify product specifications without prior notice.



Service Kit Parts



Oasis Engineering Ltd. 129 Birch Ave, Tauranga, 3110, New Zealand, Ph +64 7 9283808, info@oasisngv.com, www.oasisngv.com

We reserve the right to modify product specifications without prior notice.



Setting The Standard

1. Remove valve from vat and use lock nut tool to loosen lock nut.



2. Remove the lock nut.

- 3. Loosen wedge nut with a 10mm Allen key (3-4 turns).
- 4. Remove the handle using a 5mm Allen key.





7



Setting The Standard

5. Pull handle off.





7. Remove end cap.





8. It maybe required to use a soft hammer to tap the spindle through the cap.



8



Setting The Standard

9. Pull out the spindle and separate it from the cap. Discard cap O-ring.

10. Use a screw driver (or punch) and hammer to tap out the bush in the cap.





TAKE CARE TO NOT SCRATCH THE BODY

12. Remove plug assembly from spindle and discard O-ring and plug.



11. Use a screw driver (or punch) and hammer to tap out the bush in the body.

TAKE CARE TO NOT SCRATCH THE BODY



Oasis Engineering Ltd. 129 Birch Ave, Tauranga, 3110, New Zealand, Ph +64 7 9283808, info@oasisngv.com, www.oasisngv.com

9



Setting The Standard

13. Use pliers to remove plug Shaft.

14. Discard gland, O-ring and washers. Do not throw away shaft.





15. Discard spindle O-rings.

16. Remove adjustment wedge and nut.



10



17. If required, remove CIP and follow PV250-CIP servicing instructions.



18. Clean all components and ready for re-assembly.





1. Lightly tap a new bush into the end cap using a soft punch.



3. Measure the Internal Diameter of the bushes and ensure they are between 38.00 and 38.07mm. If the measurement is outside this tolerance a new bush must be installed. 2. Lightly tap a new bush into the body using a soft punch.



4. Apply food grade grease to the O-rings and install them on the spindle.





Setting The Standard

- 5. Apply food grade anti seize grease to the adjustment wedge and insert wedge into spindle until nut is flush with end of spindle.
- 6. Push plug and plug support together by hand.



Q

7. Place the plug in the body and using a press, push the plug so that it bites into the plug support.



8. Place O-ring onto plug support and slide gland over.



13



Setting The Standard

9. Slide Belleville washers over plug.



11. Grease O-ring with food grade grease and install into the end cap.



12. Slide spindle assembly into body, install wedge end first. It should click into place.





14



Setting The Standard

13. Install the end cap.

14. Apply anti seize to cap screws, install into body and tighten to 10 Nm.





- 15. Re attach the handle. Torque to 12 Nm.
- 16. Torque the adjusting wedge to 9Nm.





Setting The Standard

16. Tighten the adjustment wedge lock nut firmly into place.

17. Servicing complete, follow installation instructions on page 3 for re-installation of product.





Oasis Engineering Ltd. 129 Birch Ave, Tauranga, 3110, New Zealand, Ph +64 7 9283808, info@oasisngv.com, www.oasisngv.com

16